

Stainless Steel Accessories

DOOR WINDOW SHADE

INSTALLATION INSTRUCTIONS

1. Remove the mirror from passenger side door. Set hardware aside.
2. Attach supplied bracket to door using hardware set aside in step 1.
3. Attach mirror to supplied bracket using supplied hardware.
4. Disassemble mirror arm from OEM bracket and swing mirror arm away from the door.
5. Prepare the mounting surface of the door according to 3M tape instructions provided.
6. Remove the backing of tape from window shades and attach window shades to door. Refer to 3M tape instructions provided to ensure proper adhesion.
7. Reassemble the mirror arm to the OEM bracket.
8. Repeat steps 4-7 for the driver side

