

STAINLESS STEEL ACCESSORIES

CAB SKIRT – PETERBILT 579

INSTALLATION INSTRUCTIONS

1. Hold up the cab skirt to the inside of the lower door flange to check location.
2. Hold the cab skirt to the outside of the door flange and mark the mounting hole locations.
3. Drill a 5/16" hole in each location marked.
4. Attach the cab skirt to the inside of the flange using the supplied 1/4-20 hardware.