

STAINLESS STEEL ACCESSORIES

CAB SKIRT

INSTALLATION INSTRUCTIONS

1. Remove plastic from the concealed edges of the skirt.
2. Hold the skirt in the desired position below the cab and flush against the fender.

Note: Fender adjustment may be necessary to match the angle on the front of the cab skirt

3. Using a pen, transfer all mounting slots and holes to the truck to be drilled later.
4. Set the skirt aside.
5. Drill holes in each marked location using a 9/32" (preferred) or a 5/16" drill bit.
6. Attach the skirt to the truck using the supplied 1/4" hardware. For the rear most hole, attach the supplied bracket to the top and bottom flanges to stiffen the skirt.
7. Remove remaining plastic and clean with glass cleaner, if necessary.